

GARMIN GPS 72 – Collect and return to “Lulu” each race day.

CHECK BATTERIES

- Press “Menu” twice
- Power indicator is at bottom right



- Press “Quit” to return.

CHANGING BATTERIES

- Turn unit off
- Lift and rotate small screw in the back a ¼ turn anti-clockwise
- Gently pull screw handle to open
- Replace batteries – available in Lulu
- Replace using opposite steps. Ensure rubber tab covering the electrical socket is replaced.

INITIALISING

- Turn the unit on
- Press “Page”
- Wait 2-5 mins, screen will change

CREATING A WAYPOINT AT YOUR LOCATION

- Press and hold “Enter / Mark” until 2 beeps are heard
- Scroll down to “Goto” and press “Enter”
- Press “Page” to show Bearing and Dist To Next.

TURNING IT ON / OFF

- Press and hold red button



RE-ESTABLISHING A “GOTO” TO STORED WAYPOINTS IF GPS POWERS DOWN

- Turn on unit and wait for initialising to complete
- Press “GOTO” button.
- Navigate to Waypoint, press “Enter”
- Scroll to desired Waypoint and press “Enter”.
- Press “Page” until the Bearing / Dist To Next screen displays.

DELETING WAYPOINTS

- Press “Menu” twice to go to main menu
- Scroll to “Points” and press “Enter”
- Scroll to “Waypoints” and press “Enter”
- To delete a single waypoint, highlight it on the list, press “Menu” then select “Delete Waypoint”, press “Enter”, select “Yes” and press “Enter” to delete it.
- To delete ALL waypoints, highlight any waypoint, press “Menu” then select “Delete All”, press “Enter”, select “Yes” and press “Enter” to delete all waypoints.

Please delete all waypoints at the end of the day before returning the unit to Lulu.

COURSE LAYING

The general principle is that the world revolves around the Start Boat.

1. Establish a waypoint at the Start Boat once it has been anchored in position
2. RO to advise course length and bearing for top and bottom bouys from Start Boat
3. Check with RO prior to laying mark and departing for next bouy.
4. Start line – set at 90° to wind off port side of start boat, distance 1.5 * boat length * number of boats starting.
5. Gate – set at 90° to wind off startboard side of start boat at distance 75m
6. Wing mark – set at 90° to wind off port side of start boat, distance per table below:

Windward Length (NM)	Distance SB to Mark (NM)
0.4	0.12
0.5	0.14
0.6	0.17
0.7	0.20
0.8	0.23
0.9	0.26
1.0	0.29
1.1	0.32
1.2	0.35
1.3	0.38